
SRC1 Series Single-Phase, Slim Detachable Heatsink Type SSR

Single-Phase, Slim Detachable Heatsink Type SSR

Features


- Slim, compact size (22.5 mm width)
- Dielectric strength: 4000 VAC
- High heat dissipation efficiency with ceramic PCB
- Zero cross turn-on, random turn-on models available
- Input Indicator (green LED)







Ordering Information



Model	Rated input voltage	Rated load current	Rated load voltage	Function
SRC1-1215	4-30VDC	15A	24-240VAC	Zero cross turn-on
SRC1-4215	90-240VAC	TIDA		
SRC1-1220	4-30VDC	20A		
SRC1-4220	90-240VAC			
SRC1-1230	4-30VDC	204		
SRC1-4230	90-240VAC	30A		
SRC1-1420	4-30VDC		48-480VAC	Zero cross turn-on
SRC1-4420	90-240VAC	20A		
SRC1-1420R	4-30VDC			Random turn-on

(A) Photoelectric Sensors

(B) Fiber Optic

> (C) Door/Area Sensors

(D) Proximity Sensors

(E) Pressure Sensors

(F) Rotary Encoders

(G) Connectors/ Connector Cables/ Sensor Distribution Boxes/Sockets

(H) Temperature Controllers



Counters

imers

(M) Tacho / Speed / Pulse Meters

Meters

(N) Display Units

O) Sensor Controllers

(P) Switching Mode Power Supplies

(Q) Stepper Motors & Drivers & Controllers

(R) Graphic/ Logic Panels

(S) Field Network Devices

(T) Software

Autonics 1-9

Specifications

O Input

Rated input voltage range		4-30VDC	90-240VACrms~ (50/60Hz)	
Allowable input voltage range		4-32VDC==	85-264VACrms~ (50/60Hz)	
Max. input current		9mA (Zero cross turn-on), 13mA (Random turn-on)	7mArms (240VACrms∼)	
Pick-up voltage		Min. 4VDC	Min. 85VACrms∼	
Drop-out voltage		Max. 1VDC	Max. 10VACrms∼	
	Zero cross turn-on	Max. 0.5 cycle of load source + 1ms	Max. 1.5 cycle of load source + 1ms	
	Random turn-on	Max. 1ms	_	
Turn-off time		Max. 0.5 cycle of load source + 1ms	Max. 1.5 cycle of load source + 1ms	

Output

Rated load voltage range		24-240VACrms~ (50/60Hz)			48-480VACrms∼ (50/60Hz)	
Allowable load voltage range		24-264VACrms~ (50/60Hz)			48-528VACrms~ (50/60Hz)	
Rated load current	Resistive load (AC-51)*1	15Arms	20Arms	30Arms	20Arms	
Min. load current		0.15Arms	0.2Arms	0.2Arms	0.5Arms	
Max. 1 cycle surge current (60Hz)		190A	270A	330A	300A	
Max. non-repetitive surge current (I ² t, t=8.3ms)		150A ² s	300A ² s	500A ² s	350A ² s	
Peak voltage (non-repetitive)		600V			1200V (zero cross turn-on),1000V (random turn-on)	
Leakage current (Ta=25°C)		Max. 10mArms (240VAC~/60Hz)			Max. 10mArms (480VAC~/60Hz)	
Output on voltage drop[Vpk] (Max. load current)		Max. 1.6V				
Static off-state dv/dt		500V/μs				

X1: AC-51 is utilization category at IEC60947-4-3.

General Specifications

ngth (Vrms)	4000VAC~ 50/60Hz 1 min (Input-Output, Input/Output-Case)			
stance	Over 100MΩ (at 500VDC== Megger) (Input-Output, Input/Output-Case)			
	Input indicator: Green LED			
Mechanical	0.75mm amplitude at frequency of 10 to 55Hz (for 1 min) in each X, Y, Z direction for 1 hour			
Malfunction	0.5mm amplitude at frequency of 10 to 55Hz (for 1 min) in each X, Y, Z direction for 10 min			
Mechanical	300m/s² (approx. 30G) in each X, Y, Z direction for 3 times			
Malfunction	100m/s² (approx. 30G) in each X, Y, Z direction for 3 times			
Ambient temp.	-30 to 80°C (in case of the rated input voltage 90-240VAC~: -20 to 70°C), storage: -30 to 100°C (The rated load current capacity is different depending on ambient temperature. Refer to ■ SSR Derating Curve'.)			
Ambient humi.	45 to 85%RH, storage: 45 to 85%RH			
connection	Min. 1×0.5mm² (1×AWG20), Max. 1×1.5mm² (1×AWG16) or 2×1.5mm² (2×AWG16)			
al connection	Min. 1×0.75mm² (1×AWG18), Max. 1×4mm² (1×AWG12) or 2×2.5mm² (2×AWG14)			
fixed torque	0.75 to 0.95N·m			
al fixed torque	1.0 to 1.35N·m			
	(€ c PL) us			
	Approx. 119g (approx. 85g)			
	Mechanical Malfunction Mechanical Malfunction Ambient temp. Ambient humi. connection al connection fixed torque			

 $[\]times\!\!\!/\,1$: The weight includes packaging. The weight in parenthesis is for unit only. $\times\!\!\!/\,$ Environment resistance is rated at no freezing or condensation.

I-10 **Autonics**


[%]For wiring the terminal, an O-ring terminal must be used.

Single-Phase, Slim Detachable Heatsink Type SSR


Dimensions & Mounting

(unit: mm)


O Dimensions



O Hole cut-out for panel front mounting



O Installation interval




Migh temperature caution

Make sure do not touch the heat sink or the unit body while power is supplied or right after load power is turned off. If not, it may cause a burn.

※For mounting multiple SSR, please keep certain installation intervals for heat prevention.


For horizontal installation (when the heights of input part and output part are equal), it is recommended to apply 50% of rated load current.

■ Connections




SSR Derating Curve


© SRC1-1215/4215




SRC1-1220/4220



SRC1-1420/4420/1420R



SRC1-1230/4230



⚠Please supply less than 50% of the rated load current when installing several SSRs closely due to decreasing effectiveness of protection against heat.

(A) Photoelectric Sensors

(B) Fiber Optic Sensors

(C) Door/Area Sensors

(D) Proximity Sensors

(E) Pressure Sensors

(F) Rotary Encoders

(G) Connectors/ Connector Cables/ Sensor Distribution Boxes/Sockets

(H) Temperature

(I) SSRs / Power Controllers

> J) Counters

K) imers

L) Panel Meters

(M) Tacho / Speed / Puls Meters

(N) Display Units

O) Sensor Controllers

(P) Switching Mode Power Supplies

(Q) Stepper Motors

(R) Graphic/ Logic Panels

(S) Field Network

(T)

Autonics I-11

SRC1 Series

Proper Usage

Migh temperature caution

Make sure do not touch the heat sink or the unit body while power is supplied or right after load power is turned off. If not, it may cause a burn.

Cautions during use

- Attach a heatsink and ventilate for smooth convection current. If not, congested heat transfer may cause product failure or malfunction.
- 2. For mounting multiple SSR, please keep certain installation intervals for heat prevention. For horizontal installation (when the heights of input part and output part are equal), it is recommended to apply less than 50% of the rated load current.
- 3. Make sure do not touch the heatsink or the unit body while power is supplied or right after load power is turned OFF. If not, it may cause a burn.
- 4. Connect the proper cable for the rated load current with output terminal.
- 5. Use rapid fuse of which I²t is under 1/2 of SSR I²t in order to protect the unit from load's short-circuit current. In case of a short-circuit please replace the fuse which has same specification.
- 6. In case that load's current is lower than SSR min. load current, connect dummy resistance to the load in parallel so as to make load's current higher than SSR min. load current.
- 7. When selecting phase control with random turn-on model, install the noise filter between load and load's source
- 8. Make sure that the screw on output terminal is tightly fastened. Using the unit with loose bolt may cause product failure or malfunction.
- 9. Do not touch the load's terminal even if output is OFF. It may cause electric shock.
- 10. The signal input of the 4-30VDC model should be supplied by the insulated and limited voltage/current or by Class 2 power supply.
- 11. To attach the heatsink, use Thermal Grease as below or that of equal specification.
 - **Thermal Grease: GE TOSHIBA (YG6111), KANTO-KASEI (FLOIL G-600), SHINETSU (G746)
- 12. Avoid following environments to install this unit.
 - ① Where temperature/humidity is beyond the specification
 - ② Where dew condensation occurs due to temperature change
 - 3 Where inflammable or corrosive gas exists
 - 4 Where direct rays of light exist
 - (5) Where severe shock, vibration or dust exists
 - 6 Where near facilities generating strong magnetic forces or electric noise
- 13. This product may be used in the following environments.
 - 1 Indoors
 - ② Max. altitude: 2,000m
 - 3 Pollution degree 2
 - (4) Installation category III

I-12 Autonics