Panel Meters (Indicator)

M4N Series

INSTRUCTION MANUAL

TCD210073AA

Autonics

Thank you for choosing our Autonics product.

Read and understand the instruction manual and manual thoroughly before using the product.

For your safety, read and follow the below safety considerations before using. For your safety, read and follow the considerations written in the instruction manual, other manuals and Autonics website.

Keep this instruction manual in a place where you can find easily.

The specifications, dimensions, etc. are subject to change without notice for product improvement. Some models may be discontinued without notice.

Follow Autonics website for the latest information.

Safety Considerations

- · Observe all 'Safety Considerations' for safe and proper operation to avoid hazards.
- ↑ symbol indicates caution due to special circumstances in which hazards may occur.

Marning Failure to follow instructions may result in serious injury or death.

- 01. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime / disaster prevention devices, etc.)
- Failure to follow this instruction may result in personal injury, economic loss or fire.

 O2. Do not use the unit in the place where flammable / explosive / corrosive gas, high humidity, direct sunlight, radiant heat, vibration, impact or salinity may be present.
 Failure to follow this instruction may result in explosion or fire.

03. Install on a device panel to use.

Failure to follow this instruction may result in fire.

04. Do not connect, repair, or inspect the unit while connected to a power source.

Failure to follow this instruction may result in fire. **05. Check 'Connections' before wiring.**Failure to follow this instruction may result in fire.

06. Do not disassemble or modify the unit. Failure to follow this instruction may result in fire

▲ Caution Failure to follow instructions may result in injury or product damage.

01. Use the unit within the rated specifications.

ailure to follow this instruction may result in fire or product damage


- 02. Use a dry cloth to clean the unit, and do not use water or organic solvent. Failure to follow this instruction may result in fire
- 03. Keep the product away from metal chip, dust, and wire residue which flow into the unit.

Failure to follow this instruction may result in fire or product damage.

Cautions during Use

- Follow instructions in 'Cautions during Use'.
- Otherwise, It may cause unexpected accidents.
- Power supply should be insulated and limited voltage / current or Class 2, SELV power supply device
- Install a power switch or circuit breaker in the easily accessible place for supplying or disconnecting the power.
- Keep away from high voltage lines or power lines to prevent inductive noise In case installing power line and input signal line closely, use line filter or varistor at power line and shielded wire at input signal line.

Do not use near the equipment which generates strong magnetic force or high frequency noise



- This unit may be used in the following environments.
- Indoors (in the environment condition rated in 'Specifications')
- Altitude max, 2,000 m
- Pollution degrée 2
- Installation category II

Product Components

Product (+ bracket, 10-pin hirose connector)

· Instruction manual

Ordering Information

This is only for reference, the actual product does not support all combinations. For selecting the specified model, follow the Autonics webstie.

Input type

DV: DC voltage DA: DC current

DI: DC 4 - 20 mA (scaling meter)

Power supply


0:5 VDC= ± 10 % 1: 12 - 24 VDC== ± 10 %

Measurement input

	DC voltage input F.S.	DC current input F.S.
1	199.9 mV	199.9 μΑ
2	1.999 V	1.999 mA
3	19.99 V	19.99 mA
4	199.9 V	199.9 mA
Х	Option	Option


Dimensions

· Unit: mm, For the detailed drawings, follow the Autonics website.



Connections

- Socket pin no. 9, NC terminal, is not connected at inside.
- $\bullet \ \ \text{When 1 or -1 flashes with a certain measurement input, disconnect power supply and then}$
- When changing the position of the decimal point, disconnect swithcing pattern point on PCB and change the decimal point in the external terminal socket. If changing only at the external terminal socket not disconnecting switching pattern point on PCB, it displays both set point: one from PCB, one from the external terminal socket.



Specifications

Model	M4N-DV-□□	M4N-DA-□□	M4N-DI-□X
Input type	DC voltage	DC current	DC 4 - 20 mA
Max. allowable input	≈ 150 % F.S. for each measured input range		
Display method	7-segment (red) LED (character height: 10 mm)		
Display accuracy	0.2 % F.S. rdg ± 1-digi	t	
Sampling time	2.5 times / sec		
Display scale	-1999 (4-digit)		
Operation method	Dual integral method		
Sampling cycle	300 ms		
Response speed	≈ 2 sec (0 to 1999)		
Unit weight	≈ 44 g		
Approval	EAC		
Power supply	5 VDC== ± 10 % / 12 - 24 VDC== ± 10 % model		
Power consumption	2 W		
In and address or adaptation or	> 100 MO (500 VDC)		

Offic weight	1 ~ 44 g		
Approval	EAC		
Power supply	5 VDC== ± 10 % / 12 - 24 VDC== ± 10 % model		
Power consumption	2 W		
Insulation resistance	≥ 100 MΩ (500 VDC== megger)		
Dielectric strength	2,000 VAC~ 50 / 60 Hz for 1 min		
Noise immunity	± 100 V square wave noise (pulse width: 1 μ s) by the noise simulator		
Vibration	0.75 mm double amplitude at frequency of 10 to 55 Hz (for 1 minute) in each X, Y, Z direction for 1 hours		
Vibration (malfunction)	0.5 mm double amplitude at frequency of 10 to 55 Hz (for 1 minute) in each X, Y, Z direction for 10 min		
Shock	300 m/s² (≈ 30 G) in each X, Y, Z direction for 3 times		
Shock (malfunction)	100 m/s² (≈ 10 G) in each X, Y, Z direction for 3 times		
Ambient temperature	-10 to 50 °C, storage: -20 to 60 °C (no freezing or condensation)		
Ambient humidity	35 to 85 %RH, storage: 35 to 85 %RH (no freezing or condensation)		